



Spare Part No.	Part No.	Part Name	Easy Damage	Part Picture
IW 10508-SP-1	AA038000001	Sheathed cap	No	
IW 10508-SP-2	AA038000002	Gear box	No	
IW 10508-SP-3	AA038000003	Felt ring	No	
IW 10508-SP-4	AA038000004	Oil bearing II	No	
IW 10508-SP-5	AA038000005	Round snap rings shaft	No	
IW 10508-SP-6	AA038000006	O -ri ng	No	
IW 10508-SP-7	AA038000007	Output Spindle	No	
IW 10508-SP-8	AA038000008	Clutch Disc	No	
IW10508-SP-8-13	AA038000059	Gear Components	No	

IW 10508-SP-9	AA038000009	Steel ball 5	No	
IW 10508-SP-10	AA038000010	Spring	No	
IW 10508-SP-11	AA038000011	Clutch Axis	No	
IW 10508-SP-12	AA038000012	Steel ball 7	No	
IW 10508-SP-13	AA038G00013	Gear	No	
IW 10508-SP-14	AA038000014	Seal ring	No	
IW 10508-SP-15	AA038000015	Oil bearing I	No	
IW 10508-SP-16	AA038000016	Middle cap	No	

IW 10508-SP-17	AA038000017	O -ri ng	No	
IW 10508-SP-18	A1016000000	bearing 6000	No	
IW 10508-SP-19	AA038000018	Bearing clamp	No	
IW 10508-SP-20	AA038000019	Cuntersunk external toothed	No	
IW 10508-SP-21	AA038000020	cuntersunk flat head screws wNo		
IW 10508-SP-22	AA038000021	Plain washers	No	
IW 10508-SP-23	AA038000022	Parallel pins	No	
IW 10508-SP-24	AA038000023	HK081210 Needle bearing	No	
IW 10508-SP-25	AA038000024	Gears	No	

IW 10508-SP-26	AA038R00025	Rotor	No	
IW 10508-SP-27	A1010608000	Bearing 608	No	
IW 10508-SP-28	AA038000026	ST4.2*70(Screw ST4.2*70)	No	
IW 10508-SP-29	AA038000027	Breakwind	No	
IW 10508-SP-30	AA038S00028	Stator	No	
IW 10508-SP-31	AA038000029	Handle cap	No	
IW 10508-SP-32	AA038000030	Inner wire0.5*160	No	
IW 10508-SP-33	AA038000031	Deck plate	No	
IW 10508-SP-34	AA038W00032	Switch	No	

IW 10508-SP-35	AA038000033	Inductance	No	
IW10508-SP-35/37	AA038000033	Inductance	No	
IW 10508-SP-36	AA038000034	Housing	No	
IW 10508-SP-37	AA038000035	Inductance	No	
IW 10508-SP-38	AA038C00036	Carbon Brush	No	
IW 10508-SP-39	AA038000037	Brush holder	No	
IW 10508-SP-40	AA038000038	Spring	No	
IW 10508-SP-41	AA038000039	ST3.0*8(Screw ST3.0*8)	No	
IW 10508-SP-42	AA038000040	Plain Washers 5	No	
IW 10508-SP-43	AA038000041	Single coil spring lock washer	No	

IW 10508-SP-44	AA038000042	Hexagon socket head cap sc	No	
IW 10508-SP-45	AA038000043	Back cap	No	
IW 10508-SP-46	AA038000044	Screw ST4.2*16	No	
IW 10508-SP-47	AA038000045	Name plate	No	
IW 10508-SP-48	A1002000027	Cable 2*1.0 2m	No	
IW 10508-SP-49	AA038000046	Cord protector	No	
IW 10508-SP-50	AA038000047	Cord clamp	No	
IW 10508-SP-51	AA038000048	Electric circuit board	No	
IW 10508-SP-52	AA038000049	Screw ST4.2*13	No	

