



HPWR13018

Spare Part No.	Part No.	Part Name	Easy Damage	Part Picture
HPWR13018-SP-S.G	TS00001459	Spray gun	No	
HPWR13018-SP-C.T	TS00001460	Cotton thread tube	No	
HPWR13018-SP-1	QX00000116	Micro switch+copper value	No	
HPWR13018-SP-2	QX00000117	Pump head assy	No	
HPWR13018-SP-3	QX00000118	Secrw M8*18	No	
HPWR13018-SP-4	QX00000119	Bearing	No	
HPWR13018-SP-5	QX00000120	Swash plate	No	
HPWR13018-SP-6	QX00000121	Bearing 6303	No	
HPWR13018-SP-7	QX00000122	Oil Seal	No	
HPWR13018-SP-8	QX00000123	Secrw	No	
HPWR13018-SP-9	QX00000124	Cylinder	No	
HPWR13018-SP-10	QX00000125R	Rotor	No	
HPWR13018-SP-11	QX00000126	Bearing 6202	No	

HPWR13018-SP-12	QX00000127S	Stator	No	
HPWR13018-SP-13	QX00000128	Foot	No	
HPWR13018-SP-14	QX00000129	Aeolian leaf	No	
HPWR13018-SP-15	QX00000130	Fan blade cover	No	
HPWR13018-SP-16	QX00000131	House	No	
HPWR13018-SP-17	QX00000132	Capacitance	No	
HPWR13018-SP-18	QX00000133W	Switch	No	
HPWR13018-SP-19	QX00000134	Cable 2M	No	

HPWR13018

