


Spare Part No.	Part No.	Part Name	Easy Damage	Part Picture
DP133505-SP-1	DD00009334	Base	No	
DP133505-SP-2	AA033000137	Upright base	No	
DP133505-SP-3	AA033000138	Flat washer	No	
DP133505-SP-4	AA033000139	Spring washer	No	
DP133505-SP-5	AA033000140	Hex bolt	No	
DP133505-SP-6	AA033000141	Upright tube	No	
DP133505-SP-7	AA033000142	Clamp handle	No	
DP133505-SP-8	AA033000143	Handle rod	No	
DP133505-SP-8/9	DD00011896	Handle rod/handle cover	No	
DP133505-SP-9	AA033000144	Handle cover	No	
DP133505-SP-C	TS00002922	Capacitance	No	

DP133505-SP-17	AA033W00152	Switch	No	
DP133505-SP-18	AA033000153	Hex screw	No	
DP133505-SP-19	AA033000154	Adjustable handle	No	
DP133505-SP-20	AA033000155	Cushion	No	
DP133505-SP-21	AA033000156	Motor stand	No	
DP133505-SP-22	AA033000157	Compress spring	No	
DP133505-SP-23	AA033000158	Motor	No	
DP133505-SP-24	AA033000159	Box	No	

DP133505-SP-25	AA033000160	Hex bolt	No	
DP133505-SP-26	A1002000015	Cable 3*0.75mm 2m	No	
DP133505-SP-27	AA033000161	Hex screw	No	
DP133505-SP-28	AA033000162	Motor belt wheel	No	
DP133505-SP-29	AA033000163	Belt wheel cover	No	
DP133505-SP-30	AA033000164	Triangle belt	No	
DP133505-SP-31	AA033000165	Cross screw	No	
DP133505-SP-32	AA033000166	Flat washer	No	
DP133505-SP-33	AA033000167	Handle	No	
DP133505-SP-34	AA033000168	Cross screw	No	
DP133505-SP-35	AA033000169	Flat washer	No	
DP133505-SP-36	AA033000170	Groove block	No	
DP133505-SP-37	AA033000171	Nut	No	

DP133505-SP-38	AA033000172	Protective coil	No	
DP133505-SP-39	AA033000173	Damping washer	No	
DP133505-SP-40	AA033000174	Hex thick nut	No	
DP133505-SP-41	AA033000175	Spring cover	No	
DP133505-SP-42	AA033000176	Scroll spring	No	
DP133505-SP-43	AA033000177	Flat washer	No	
DP133505-SP-44	AA033000178	Cross screw	No	
DP133505-SP-45	AA033000179	Main axis belt wheel	No	
DP133505-SP-46	AA033000180	Stop collar	No	
DP133505-SP-47	AA033000181	Square axis sleeve	No	
DP133505-SP-48	AA033000182	Hole stop collar	No	
DP133505-SP-49	A1016203000	6203 Bearing	No	

DP133505-SP-50	AA033000183	Fixed board	No	
DP133505-SP-51	AA033000184	Selflocked switch	No	
DP133505-SP-53	AA033000186	Switch box	No	
DP133505-SP-54	AA033000187	Spring washer	No	
DP133505-SP-55	AA033000188	Grounding wire	No	
DP133505-SP-56	AA033000189	Dental pad	No	
DP133505-SP-57	AA033000190	Screw	No	
DP133505-SP-58	AA033000191	Base	No	
DP133505-SP-59	AA033000192	Spring	No	
DP133505-SP-60	AA033000193	Nut	No	
DP133505-SP-61	AA033000194	Plate	No	
DP133505-SP-62	AA033000195	Ball	No	
DP133505-SP-64	AA033000197	Ball cover	No	
DP133505-SP-65	AA033000198	Screw	No	
DP133505-SP-66	AA033000199	Handle parts	No	

DP133505-SP-67	AA033000200	Stand base	No	
DP133505-SP-68	AA033000201	Working table	No	
DP133505-SP-69	AA033000202	Spring washer	No	
DP133505-SP-70	AA033000203	Bolt	No	
DP133505-SP-71	AA033000204	Indicator	No	
DP133505-SP-72	AA033000205	Limited bolt	No	
DP133505-SP-73	AA033000206	Guide base	No	
DP133505-SP-74	AA033000207	Hex bolt	No	
DP133505-SP-75	AA033000208	Stop collar	No	
DP133505-SP-76	A1016201000	Bearing 6201	No	

DP133505-SP-77	AA033000209	Cushion	No	
DP133505-SP-78	AA033000210	Main axis sleeve	No	
DP133505-SP-79	AA033000211	Main axis	No	
DP133505-SP-80	AA033000212	Chuck	No	
DP133505-SP-81	AA033000213	Chuck spanner	No	
DP133505-SP-82	AA033000214	Hex spanner	No	
DP133505-SP-83	AA033000215	Hex spanner	No	
DP133505-SP-C.B	BC00000164	Color box	No	

DP133505-SP-P.M	BC00000528	Product manual	No	
DP133505-SP-52.1	AA033000185	Cross screw	No	

