







BAS3502

Spare Part No.	Part No.	Part Name	Easy Damage	Part Picture
BAS3502-SP-M.S	TS00001355	microswitch	No	
BAS3502-SP-1	DD00000271	Bolt	No	
BAS3502-SP-2	DD00000272	Lower Bezel Panel	No	
BAS3502-SP-3	DD00000273	Hinge	No	
BAS3502-SP-4	DD00000274	Cross-Shaped Sunk Bolt	No	
BAS3502-SP-5	DD00000275C	Brush	No	
BAS3502-SP-6	DD00000276	Flat Washer	No	
BAS3502-SP-7	DD00000277	Cross-Shaped Self-Tapping	No	
BAS3502-SP-8	DD00000278	Door Holder	No	
BAS3502-SP-9	DD00000279	Door Lock Spring	No	
BAS3502-SP-10	DD00000280	Nut	No	
BAS3502-SP-11	DD00000281	Flat Washer	No	
BAS3502-SP-12	DD00000282	Pressing Paw	No	
BAS3502-SP-13	DD00000283	Cross-Shaped Bolt	No	
BAS3502-SP-14	DD00000284	Upper Bezel Panel	No	
BAS3502-SP-15	DD00000285	Bezel Panel Lens	No	
BAS3502-SP-16	DD00000286	Cross-Shaped Self-Tapping	No	
BAS3502-SP-17	DD00000287	Shield	No	
BAS3502-SP-18	DD00000288	Spring	No	
BAS3502-SP-19	DD00000289	Cross-Shaped Self-Tapping	No	
BAS3502-SP-20	DD00000290	Sliding Block (B)	No	
BAS3502-SP-21	DD00000291	Sliding Block (C)	No	
BAS3502-SP-22	DD00000292	Sliding Block (A)	No	
BAS3502-SP-23	DD00000293	Up-Down Part	No	
BAS3502-SP-24	DD00000294	Bolt	No	
BAS3502-SP-25	DD00000295	Bolt	No	
BAS3502-SP-26	DD00000296	Round Pin	No	
BAS3502-SP-27	DD00000297	Bracket (A)	No	
BAS3502-SP-28	DD00000298	Set Screw	No	
BAS3502-SP-29	DD00000299	Bearing	No	
BAS3502-SP-30	DD00000300	Pin Stop (B)	No	
BAS3502-SP-31	DD00000301	Bolt	No	
BAS3502-SP-32	DD00000302	Spring Washer	No	
BAS3502-SP-33	DD00000303	Split Washer	No	
BAS3502-SP-34	DD00000304	Fixed Pin	No	
BAS3502-SP-35	DD00000305	Fixed Block	No	
BAS3502-SP-36	DD00000306	Nut	No	
BAS3502-SP-37	DD00000307	Moving Block	No	
BAS3502-SP-38	DD00000308	Shaft For Driven Wheel	No	

BAS3502-SP-39	DD00000309	Bearing	No	
BAS3502-SP-40	DD00000310	Retainer Ring For Hole	No	
BAS3502-SP-41	DD00000311	Driven Wheel	No	
BAS3502-SP-42	DD00000312	Rubber Band	No	
BAS3502-SP-43	DD00000313	Retainer Ring For Shaft	No	
BAS3502-SP-44-F	AA036000042	Blade	No	
BAS3502-SP-44	DD00000314	Blade	No	
BAS3502-SP-45	DD00000315W	Lock Switch	No	
BAS3502-SP-46	DD00000316	Cross-Shaped Bolt	No	
BAS3502-SP-47	DD00000317	Switch Box	No	
BAS3502-SP-48	DD00000318	Cross-Shaped Bolt	No	
BAS3502-SP-49	DD00000319	Spring Washer	No	
BAS3502-SP-50	DD00000320	Grounding Terminal	No	
BAS3502-SP-51	DD00000321	Gear Pad	No	
BAS3502-SP-52	DD00000322	Grounding Signal	No	
BAS3502-SP-53	DD00000323	Locking Plate	No	
BAS3502-SP-54	DD00000324	Flat Washer	No	
BAS3502-SP-55	DD00000325	Spring Washer	No	
BAS3502-SP-56	DD00000326	Bolt	No	
BAS3502-SP-57	DD00000327	Shaft For Driving Wheel	No	
BAS3502-SP-58	DD00000328	Synchronize Wheel (B)	No	
BAS3502-SP-59	DD00000329	Synchronize Belt	No	
BAS3502-SP-60	DD00000330	Cross-Shaped Self-Tapping	No	


BAS3502-SP-61	DD00000331	Driving Wheel	No	
BAS3502-SP-62	DD00000332	Fixed Pin (A)	No	
BAS3502-SP-63	DD00000333	Bracket (B)	No	
BAS3502-SP-64	DD00000334	Lower Fixed Block	No	
BAS3502-SP-65	DD00000335	Cap Nut	No	
BAS3502-SP-66	DD00000336	Big Flat Washer	No	
BAS3502-SP-67	DD00000337	Footing	No	
BAS3502-SP-68	DD00000338	Hexagon Bolt	No	
BAS3502-SP-69	DD00000339	Body	No	
BAS3502-SP-70	DD00000340	Supporting	No	
BAS3502-SP-71	DD00000341	Hexagon Bolt	No	
BAS3502-SP-72	DD00000342	Clip	No	
BAS3502-SP-73	DD00000343	Hexagon Bolt	No	
BAS3502-SP-74	DD00000344	Nut	No	
BAS3502-SP-75	DD00000345	Dust Outlet	No	
BAS3502-SP-76	DD00000346	Angle Adjusting Gear	No	
BAS3502-SP-77	DD00000347	Spring	No	
BAS3502-SP-78	DD00000348	Flat Washer	No	
BAS3502-SP-79	DD00000349	Bolt	No	
BAS3502-SP-80	DD00000350	Bolt	No	
BAS3502-SP-81	DD00000351	Bolt	No	
BAS3502-SP-82	DD00000352	Indicator	No	
BAS3502-SP-83	DD00000353	Locating Sleeve	No	
BAS3502-SP-84	DD00000354G	Adjusting Gear	No	
BAS3502-SP-85	DD00000355	Locating Sleeve (A)	No	
BAS3502-SP-86	DD00000356	Wave-Shaped Washer	No	

BAS3502-SP-87	DD00000357	Up-Down Knob	No	
BAS3502-SP-88	DD00000358	Protecting Bush	No	
BAS3502-SP-89	DD00000359	Locking Knob	No	
BAS3502-SP-90	DD00000360	Power Cord 2M	No	
BAS3502-SP-91	DD00000361	Bolt	No	
BAS3502-SP-92	DD00000362	Flat Washer	No	
BAS3502-SP-93	DD00000363	Fixed Plate Assembly	No	
BAS3502-SP-94	DD00000364	Cord Clip	No	
BAS3502-SP-95	DD00000365	Nut	No	
BAS3502-SP-96	DD00000366	Fine Adjusting Knob	No	
BAS3502-SP-97	DD00000367	Spring	No	
BAS3502-SP-98	DD00000368	Eccentricity Shaft	No	
BAS3502-SP-99	DD00000369	Wave-Shaped Washer	No	
BAS3502-SP-100	DD00000370	Locating Sleeve (B)	No	
BAS3502-SP-101	DD00000371	Compression Handle	No	
BAS3502-SP-102	DD00000372	Roller	No	
BAS3502-SP-103	DD00000373	Block	No	
BAS3502-SP-104	DD00000374	Bolt	No	
BAS3502-SP-105	DD00000375	Box	No	
BAS3502-SP-107	DD00000376	Bolt	No	
BAS3502-SP-108	DD00000377	Cover	No	
BAS3502-SP-109	DD00000378	Bolt	No	

BAS3502-SP-110	DD00000379	Square-Neck Bolt	No	
BAS3502-SP-111	DD00000380	Compression Spring	No	
BAS3502-SP-112	DD00000381	Swelling Knob	No	
BAS3502-SP-113	DD00000382	Locknut	No	
BAS3502-SP-114	DD00000383	Lower Shield (A)	No	
BAS3502-SP-115	DD00000384	Lower Shield (B)	No	
BAS3502-SP-116	DD00000385	Bolt	No	
BAS3502-SP-117	DD00000386	Clamp Handle	No	
BAS3502-SP-118	DD00000387	Spring Round Pin	No	
BAS3502-SP-119	DD00000388	Big Flat Washer	No	
BAS3502-SP-120	DD00000389	Connecting Screw Rod	No	
BAS3502-SP-121	DD00000390	Fixed Pressing Paw	No	
BAS3502-SP-122	DD00000391	Guide Tube	No	
BAS3502-SP-123	DD00000392	Hexagon Bolt	No	
BAS3502-SP-124	DD00000393	Connecting Rod	No	
BAS3502-SP-125	DD00000394	Square Washer (A)	No	
BAS3502-SP-126	DD00000395	Spring	No	
BAS3502-SP-127	DD00000396	Movable Clamp Paw	No	
BAS3502-SP-128	DD00000397	Bolt	No	
BAS3502-SP-129	DD00000398	Knob For Mitre Angle	No	
BAS3502-SP-130	DD00000399	Mitre Angle	No	
BAS3502-SP-131	DD00000400	Pointer	No	
BAS3502-SP-132	DD00000401	Fence	No	
BAS3502-SP-133	DD00000402	Worktable	No	
BAS3502-SP-134	DD00000403	Table Insert	No	
BAS3502-SP-135	DD00000404	Bolt	No	
BAS3502-SP-136	DD00000405	Snap Gauge	No	
BAS3502-SP-137	DD00000406	Bolt	No	
BAS3502-SP-138	DD00000407	Cushion Cap	No	
BAS3502-SP-139	DD00000408	Wing Bolt	No	
BAS3502-SP-140	DD00000409	Spring Washer	No	
BAS3502-SP-141	DD00000410	Bolt	No	
BAS3502-SP-142	DD00000411	Mitre Seat	No	

BAS3502-SP-143	DD00000412	Lock Bolt	No	
BAS3502-SP-144	DD00000413	Securing Handle	No	
BAS3502-SP-145	DD00000414	Compression Spring	No	
BAS3502-SP-146	DD00000415	Bolt	No	
BAS3502-SP-147	DD00000416	Big Flat Washer	No	
BAS3502-SP-148	DD00000417	Synchronize Wheel (A)	No	
BAS3502-SP-149	DD00000418	Motor	No	
BAS3502-SP-150	DD00000419	Bolt	No	
BAS3502-SP-151	DD00000420	Push Stick	No	
BAS3502-SP-152	DD00000421	Spanner	No	
BAS3502-SP-153	DD00000422	Spanner	No	
BAS3502-SP-156	DD00000423	Scale Label	No	
BAS3502-SP-157	DD00000424	Worktable Steel Board	No	
BAS3502-SP-158	DD00000425	Nut	No	
BAS3502-SP-159	DD00000426	Uncork Pin	No	
BAS3502-SP-160	DD00000427	Butterfly Bolt	No	
BAS3502-SP-161	DD00000428	Expand Pole	No	
BAS3502-SP-162	DD00000429	Extension Table	No	
BAS3502-SP-163	DD00000430	Washer	No	
BAS3502-SP-164	DD00000431	Spring Washer	No	
BAS3502-SP-165	DD00000432	Lock Nut	No	
BAS3502-SP-166	DD00000433	Star-Head Pan Head Screws	No	

BAS3



3502

