


COS35538

Spare Part No.	Part No.	Part Name	Easy Damage	Part Picture
COS35538-SP-CABLE	TS00000111	Cable 3*1.5 2M	No	
COS35538-SP-1	AA040000081	M6*18 Screw	No	
COS35538-SP-2	AA040000082	Rubber feet	No	
COS35538-SP-3	AA040000250	Base Plate	No	
COS35538-SP-4	AA040000251	Hexagon Socket Screw	No	
COS35538-SP-5	AA040000085	M6 nut	No	
COS35538-SP-6	AA040000086	6 cushion	No	
COS35538-SP-7/8/9	AA040000087	Lock Screw Assembly	No	
COS35538-SP-10	AA040000090	2.5*20 Pin	No	
COS35538-SP-11	AA040000091	M8X20Screw +Flate Washer	No	
COS35538-SP-12/13/14	AA040000092	Nut Holder Assembly	No	
COS35538-SP-15	AA040000095	10X35 Pin	No	
COS35538-SP-16	AA040000096	M8 Nut	No	
COS35538-SP-17	AA040000097	Φ10*25 Flat Washer	No	
COS35538-SP-18	AA040000098	Small Fence	No	
COS35538-SP-19	AA040000099	Straight Pin	No	

COS35538-SP-20	AA040000100	Big Fence	No	
COS35538-SP-21	AA040000101	Φ10 Flat Washer	No	
COS35538-SP-22	AA040000102	M10X20 Screw	No	
COS35538-SP-23	AA040000103	M8*12 screw	No	
COS35538-SP-24	AA040000104	Sand Plate	No	
COS35538-SP-25	AA040000105	M8 Nut	No	
COS35538-SP-26	AA040000106	M8X45 Screw	No	
COS35538-SP-27	AA040000107	Washer 10*28*1	No	
COS35538-SP-28	AA040000108	Shaft	No	
COS35538-SP-29	AA040000109	Spring	No	
COS35538-SP-30	AA040000110	M5*16 Screw	No	
COS35538-SP-31	AA040000111	motor cover	No	
COS35538-SP-32	AA040000112	M5*16 Screw	No	
COS35538-SP-33	AA040000113	Limit Pin	No	
COS35538-SP-34	AA040000114	9*1.5 O-RING	No	
COS35538-SP-35	AA040000115	Φ8 Circlip	No	
COS35538-SP-36	DD00001199	Brush Holder	No	
COS35538-SP-37	AA040C00117	Carbon Brush	No	
COS35538-SP-38-F	AA040000118	Carbon brush cap	No	

COS35538-SP-38	DD00001200	Carbon Brush Cap	No	
COS35538-SP-39	DD00001201	Motor Housing	No	
COS35538-SP-40	AA04S000252	Stator	No	
COS35538-SP-41	AA040000121	Φ5 Washer	No	
COS35538-SP-42	AA040000122	M5X75 Screw&flat washer	No	
COS35538-SP-43	A1016200000	6200RS bearing	No	
COS35538-SP-44	AA04R000253	Rotor	No	
COS35538-SP-45	AA040000124	Baffle	No	
COS35538-SP-46	A1016202000	Bearings 6202	No	
COS35538-SP-47	AA040000125	Gear box	No	

COS35538-SP-48	AA040000126	Lock Pin Spring	No	
COS35538-SP-49	AA040000127	Spindle lock pin	No	
COS35538-SP-50	A1010608000	Bearing 608	No	
COS35538-SP-51	AA040000128	Φ20 Circlip	No	
COS35538-SP-52	AA040G00129	Gear	No	
COS35538-SP-53	DD00001202	Gear Box Cover	No	
COS35538-SP-54	A1016204000	Deep Groove Ball Bearing 608	No	
COS35538-SP-55	AA040000131	6*6*18 Woodruff Key	No	
COS35538-SP-56	AA040000132	Spindle	No	
COS35538-SP-57	AA040000133	M6X10 Screw	No	

COS35538-SP-58	AA040000134	Small safety guard	No	
COS35538-SP-59	AA040000135	M6 Nut	No	
COS35538-SP-60	AA040000136	Safety guard	No	
COS35538-SP-61/62/63	AA040000137	Combination Screw M5*55	No	
COS35538-SP-64	AA040000140	Inner flange	No	
COS35538-SP-65	AA004000475	Wheel	No	
COS35538-SP-66	AA040000142	Outer flange	No	
COS35538-SP-67	AA040000143	washer	No	
COS35538-SP-68	AA040000144	M10X20 Screw	No	

COS35538-SP-69	AA0040000476	Side Cover	No	
COS35538-SP-70	AA040000146	M6X10 Screw	No	
COS35538-SP-71	AA040000147	M6X1Screw	No	
COS35538-SP-72	AA040000148	ST4.2*16	No	
COS35538-SP-73	AA040000149	M5X45 Screw	No	
COS35538-SP-74	AA040000150	M5 Nut	No	
COS35538-SP-75	AA040000151	Left&Right handle	No	
COS35538-SP-75/79	AA040000151	Left&Right handle	No	
COS35538-SP-76	AA040000152	ST4.2*16	No	
COS35538-SP-77	AA040000153	Cord Clamp	No	
COS35538-SP-78	AA040000154	Cord Guard	No	
COS35538-SP-79	AA040000155	Right handle	No	
COS35538-SP-80	AA040W00156	Switch	No	
COS35538-SP-81	AA040000157	M16 Nut	No	
COS35538-SP-82	AA040000158	M16*160 Screw	No	
COS35538-SP-83-F	A1002000024	Cable 3*1.5 2M	No	
COS35538-SP-83	TS00000111	Cable 3*1.5 2M	No	

COS35538-SP-83-V1	DD00001203	Spring Washer 10	No	
-------------------	------------	------------------	----	--

COS35538

