




## HPWR28008

| Spare Part No.         | Part No.    | Part Name                 | Easy Damage | Part Picture                                                                          |
|------------------------|-------------|---------------------------|-------------|---------------------------------------------------------------------------------------|
| HPW R28008-SP-O.S      | CC000000146 | Oil Seal                  | No          |    |
| HPW R28008-SP-INLET.VA | TS000000026 | YLP08Z.1 Inlet Valve Assy | No          |    |
| HPW R28008-SP-OUTLET.V | TS00000114  | Outlet valve              | No          |    |
| HPW R28008-SP-W .S     | TS00000115  | Water Seal Base           | No          |    |
| HPW R28008-SP-M.S      | TS00000349  | Micro Switch              | No          |  |
| HPW R28008-SP-P.A      | TS00000279  | YLP08 PISTON-ASSY         | No          |                                                                                       |
| HPW R28008-SP-P.T.B    | TS00000486  | Plain thrust bearing      | No          |  |
| HPW R28008-SP-Y.RING   | TS00000071  | Y-Ring 20X12              | No          |                                                                                       |
| HPW R28008-SP-O.V      | TS00000033  | Outlet Valve              | No          |  |
| HPW R28008-SP-P.S      | TS00000074  | Piston Seal               | No          |                                                                                       |
| HPW R28008-SP-S.B      | TS00000075  | Sealing Base              | No          |                                                                                       |
| HPW R28008-SP-E-3      | TS00000486  | Plain thrust bearing      | No          |                                                                                       |
| HPW R28008-SP-E-6      | TS00000067  | Pump Head Kit             | No          |                                                                                       |
| HPW R28008-SP-E-7      | TS00000068  | Copper Pump Head          | No          |                                                                                       |
| HPW R28008-SP-E-8      | TS00000026  | YLP08Z.1 Inlet Valve Assy | No          |                                                                                       |
| HPW R28008-SP-E-9      | TS00000033  | Outlet Valve              | No          |  |
| HPW R28008-SP-E-10     | TS00000070  | Copper-Valve Plug         | No          |                                                                                       |
| HPW R28008-SP-E-11     | TS00000071  | Y-Ring 20X12              | No          |                                                                                       |

|                                     |             |                                |    |                                                                                       |
|-------------------------------------|-------------|--------------------------------|----|---------------------------------------------------------------------------------------|
| HPW R28008-SP-E-13                  | TS00000115  | Water Seal Base                | No |                                                                                       |
| HPW R28008-SP-E-19                  | TS00000279  | YLP08 PISTON-ASSY              | No |                                                                                       |
| HPW R28008-SP-E-21                  | TS00000077  | Siphon Head Assembly           | No |                                                                                       |
| HPW R28008-SP-E-22                  | TS00000078  | Venturi-Tube Kit               | No |                                                                                       |
| HPW R28008-SP-E-23                  | TS00000783  | valve assembly                 | No |                                                                                       |
| HPW R28008-SP-E-23                  | TS00000349  | Micro Switch                   | No |                                                                                       |
| HPW R28008-SP-E-31                  | QX00000274  | Swash plate11                  | No |                                                                                       |
| HPW R28008-SP-E-2 HPW R28008-SP-E-4 | QX00000275  | ST screw M6*20/ROHS            | No |                                                                                       |
| HPW R28008-SP-E-12                  | QX00000277  | O-ring12.5X1.8                 | No |    |
| HPW R28008-SP-E-14                  | QX00000278  | ST screw M6*8                  | No |                                                                                       |
| HPW R28008-SP-E-15                  | QX00000279  | YLP08 piston guider kit        | No |                                                                                       |
| HPW R28008-SP-E-16                  | QX00000280  | piston guider                  | No |                                                                                       |
| HPW R28008-SP-E-17                  | CC000000146 | Oil Seal                       | No |    |
| HPW R28008-SP-E-18                  | QX00000282  | sealing base                   | No |   |
| HPW R28008-SP-E-20                  | QX00000283  | chief valve assy with self suc | No |  |
| HPW R28008-SP-E-24                  | QX00000284  | o-ring 70X2                    | No |  |
| HPW R28008-SP-E-25                  | QX00000285  | washer $\phi$ 6                | No |  |
| HPW R28008-SP-E-26                  | QX00000286  | spring washer $\phi$ 6-ROHS    | No |  |
| HPW R28008-SP-E-27                  | QX00000287  | ST screwM6*70                  | No |                                                                                       |

|                       |             |                        |    |                                                                                       |
|-----------------------|-------------|------------------------|----|---------------------------------------------------------------------------------------|
| HPW R28008-SP-E-28    | QX00000288  | external circlip D15   | No |                                                                                       |
| HPW R28008-SP-E-29    | QX00000289  | motor fan              | No |    |
| HPW R28008-SP-E-30    | QX00000290  | M18 motor cover        | No |                                                                                       |
| HPW R28008-SP-E-32    | TS00000080  | Inlet Filter           | No |                                                                                       |
| HPW R28008-SP-E-17-V1 | QX00000281  | piston seal            | No |                                                                                       |
| HPW R28008-SP-H.P.A   | TS00001721  | Homemade pump assembly | No |    |
| HPW R28008-SP-P.S1    | TS00001777  | plunger spring         | No |                                                                                       |
| HPW R28008-SP-1-4     | AD001000165 | ST screw               | No |                                                                                       |
| HPW R28008-SP-1       | AD001000161 | Front Casing Assembly  | No |                                                                                       |
| HPW R28008-SP-1-1     | AD001000162 | Switch Board           | No |   |
| HPW R28008-SP-1-2     | AD001000163 | Front Casing           | No |                                                                                       |
| HPW R28008-SP-1-3     | AD001000164 | Logo Board-Ingco       | No |                                                                                       |
| HPW R28008-SP-2-2     | AD001000168 | Pump Assembly          | No |  |
| HPW R28008-SP-2-1     | AD001000167 | Motor                  | No |  |
| HPW R28008-SP-2       | AD001000166 | Motor And Pump Assy    | No |  |
| HPW R28008-SP-3       | AD001000169 | ST screw               | No |  |
| HPW R28008-SP-4       | AD001000170 | Induction Motor Clamp  | No |  |

|                     |             |                    |    |                                                                                       |
|---------------------|-------------|--------------------|----|---------------------------------------------------------------------------------------|
| HPW R28008-SP-5     | AD001000040 | Water connector    | No |    |
| HPW R28008-SP-      | AD001000172 | Water inlet cover  | No |                                                                                       |
| 6 HPW R28008-       | AD001000173 | Screw              | No |                                                                                       |
| SP-7 HPW            | AD001000174 | Screw              | No |                                                                                       |
| R28008-SP-8         |             |                    |    |                                                                                       |
| HPW R28008-SP-9     | AD001000175 | Pump Base          | No |    |
| HPW R28008-SP-      | AD001000176 | ST screw           | No |                                                                                       |
| 10 HPW R28008-      | AD001000177 | Capacitor clamp    | No |                                                                                       |
| SP-11               |             |                    |    |                                                                                       |
| HPW R28008-SP-12    | AD001000178 | Capacitor sheath   | No |   |
| HPW R28008-SP-      | AD001000179 | Capacitor          | No |                                                                                       |
| 13 HPW R28008-      | AD001000180 | Washer 4           | No |                                                                                       |
| SP-14               |             |                    |    |                                                                                       |
| HPW R28008-SP-15    | AD001000181 | Spring Washer 4    | No |  |
| HPW R28008-SP-16    | AD001000182 | Motor damping Ring | No |  |
| HPW R28008-SP-17    | AD001000183 | Soap Pipe          | No |  |
| HPW R28008-SP-18-1  | AD001000185 | ST screw           | No |                                                                                       |
| HPW R28008-SP-18-2  | AD001000186 | Cable Seal         | No |                                                                                       |
| HPW R28008-SP-18-3  | AD001000187 | ST screw           | No |                                                                                       |
| HPW R28008-SP-18-5  | AD001000189 | Waterproof         | No |                                                                                       |
| HPW R28008-SP-18-8  | AD001000192 | Wheel Axle         | No |                                                                                       |
| HPW R28008-SP-18-9  | AD001000193 | circlip            | No |                                                                                       |
| HPW R28008-SP-18-   | AD001000197 | Flat Washer        | No |                                                                                       |
| 13                  |             |                    |    |                                                                                       |
| HPW R28008-SP-18-18 | AD001000202 | Switch Lever       | No |  |
| HPW R28008-SP-18-20 | AD001000204 | ST screw           | No |                                                                                       |

|                     |             |                       |    |                                                                                       |
|---------------------|-------------|-----------------------|----|---------------------------------------------------------------------------------------|
| HPW R28008-SP-18-23 | AD001000207 | 0-RING                | No |                                                                                       |
| HPW R28008-SP-18    | AD001000184 | Rear Casing Assembly  | No |                                                                                       |
| HPW R28008-SP-18-4  | AD001000188 | Switch Knob           | No |                                                                                       |
| HPW R28008-SP-18-6  | AD001000190 | Left Wheel Eave       | No |                                                                                       |
| HPW R28008-SP-18-7  | AD001000191 | Right Wheel Eave      | No |                                                                                       |
| HPW R28008-SP-18-10 | AD001000194 | Wheel Assembly        | No |                                                                                       |
| HPW R28008-SP-18-11 | AD001000195 | Wheel Cover           | No |                                                                                       |
| HPW R28008-SP-18-12 | AD001000196 | Tyre                  | No |                                                                                       |
| HPW R28008-SP-18-14 | AD001000198 | Rear Casing           | No |                                                                                       |
| HPW R28008-SP-18-15 | AD001000199 | Wheel                 | No |                                                                                       |
| HPW R28008-SP-18-16 | AD001000200 | Waterproof            | No |                                                                                       |
| HPW R28008-SP-18-17 | AD001000201 | Front Switch          | No |    |
| HPW R28008-SP-18-19 | AD001000203 | Switch                | No |    |
| HPW R28008-SP-18-21 | AD001000205 | Cl aboard             | No |                                                                                       |
| HPW R28008-SP-18-22 | AD001000206 | Back Switch Cover     | No |                                                                                       |
| HPW R28008-SP-19    | AD001000208 | Gun Stock             | No |                                                                                       |
| HPW R28008-SP-20    | AD001000209 | Gun Holder            | No |                                                                                       |
| HPW R28008-SP-21    | AD001000210 | Cleaning Pin          | No |                                                                                       |
| HPW R28008-SP-22    | AD001000211 | Pipe connector        | No |                                                                                       |
| HPW R28008-SP-23    | AD001000212 | Hose Reel Right Cover | No |  |
| HPW R28008-SP-23/24 | QX00000232  | Hose Reel Cover Assy  | No |  |
| HPW R28008-SP-24    | AD001000213 | Hose Reel Left Cover  | No |                                                                                       |
| HPW R28008-SP-25    | AD001000214 | ST screw              | No |                                                                                       |
| HPW R28008-SP-26    | AD001000215 | Right Hose Reel Cover | No |                                                                                       |
| HPW R28008-SP-27    | AD001000216 | Hose Reel Lever       | No |                                                                                       |
| HPW R28008-SP-28    | AD001000217 | Hose Reel Handle      | No |                                                                                       |
| HPW R28008-SP-29    | AD001000218 | Inner Pressure hose   | No |  |

|                         |             |                       |    |                                                                                       |
|-------------------------|-------------|-----------------------|----|---------------------------------------------------------------------------------------|
| HPW R28008-SP-30/32     | AD001000219 | Spray Gun/Spray Lance | No |    |
| HPW R28008-SP-30/32-OLD | AD001000419 | Spray Gun/Spray Lance | No |                                                                                       |
| HPWR28008-SP-30         | QX00000298  | Spray Gun             | No |    |
| HPW R28008-SP-31        | AD001000220 | Cable 5M              | No |    |
| HPW R28008-SP-32        | QX00000299  | Spray Lance           | No |                                                                                       |
| HPW R28008-SP-33        | AD001000222 | Pressure hose         | No |   |
| HPW R28008-SP-34        | AD001000223 | Soap Tank             | No |  |

