

# GT3512

Spare Part No.	Part No.	Part Name	Easy Damage	Part Picture
GT3512-SP-2	GC00000580	Casing pipe	No	
GT3512-SP-3	GC00000581	Crimping board	No	
GT3512-SP-4	GC00000582	Capacitance 0.22uf	No	
GT3512-SP-5	GC00000583	Left handle	No	
GT3512-SP-6	GC00000584	Switch	No	
GT3512-SP-7	GC00000585	Self tapping screw	No	
GT3512-SP-8	GC00000586	Right handle	No	
GT3512-SP-9	GC00000587	Self tapping screw with pad	No	
GT3512-SP-10	GC00000588	Switch button spring	No	
GT3512-SP-11	GC00000589	switch button	No	
GT3512-SP-12	GC00000590	Telescopic tube assembly	No	
GT3512-SP-13	GC00000591	I-nut M4	No	
GT3512-SP-14	GC00000592	auxiliary handle	No	
GT3512-SP-15	GC00000593	Auxiliary handle lock button	No	
GT3512-SP-16	GC00000594	Locking bolt	No	
GT3512-SP-17	GC00000595	Auxiliary handle seat	No	
GT3512-SP-18	GC00000596	I-nut M6	No	
GT3512-SP-19	GC00000597	Locking wrench	No	
GT3512-SP-20	GC00000598	Lock nut M5	No	
GT3512-SP-21	GC00000599	Spring line	No	
GT3512-SP-22	GC00000600	Cross padded screw	No	
GT3512-SP-23	GC00000601	Cross groove bolt	No	
GT3512-SP-24	GC00000602	Magnetic ring	No	
GT3512-SP-25	GC00000603	Right housing	No	
GT3512-SP-26	GC00000604	Self tapping screw with pad	No	
GT3512-SP-27	GC00000605	Motor	No	

GT3512-SP-28	GC00000606	Left housing	No	
GT3512-SP-29	GC00000607	axle sleeve	No	
GT3512-SP-30	GC00000608	shim	No	
GT3512-SP-31-36	GC00000610	Timmer Grass	No	
GT3512-SP-37	GC00000816	Shield	No	
GT3512-SP-38	GC00000611	Self tapping screw with pad	No	
GT3512-SP-39	GC00000612	Self tapping screw	No	
GT3512-SP-40	GC00000613	Blade plastic bracket + blade	No	
GT3512-SP-41	GC00000614	Terminal cap ce2x	No	

# GT3512



