

Spare Part No.	Part No.	Part Name	Easy Damage	Part Picture
CGTLI203285-SP-1/2	AAA40004601	Knob	No	
CGTLI203285-SP-3	AAA40004501	Auxiliary Handle	No	
CGTLI203285-SP-4	AAA52700301	Screw ST3.5*16	No	
CGTLI203285-SP-5/14	AAA40004101	Left &Right handle	No	
CGTLI203285-SP-6	AAA40004301	Aluminium tube plug	No	
CGTLI203285-SP-7	AAA61100503	Terminal B	No	
CGTLI203285-SP-8	AAA60500601	Micro Switch	Yes	
CGTLI203285-SP-9	AAA61100101	Electrode Holder	No	
CGTLI203285-SP-9/10	AAA21000504	PCB board/electrode holder	No	
CGTLI203285-SP-10	AAA21000504	PCB board/electrode holder	No	
CGTLI203285-SP-11	AAA40004401	Trigger	No	

CGTLI203285-SP-12	AAA52900201	Spring	No	
CGTLI203285-SP-13	AAA40004201	Push button	No	
CGTLI203285-SP-15	AAA52701501	Screw Bolt	No	
CGTLI203285-SP-16	AAA60800101	Spring Line	No	
CGTLI203285-SP-17-19	AAA40017801	Trimming wheel Assy	No	
CGTLI203285-SP-20	AAA52701602	Screw	No	
CGTLI203285-SP-21	AAA52003001	Spring Flat	No	
CGTLI203285-SP-22	AAA52002701	Fixed plate	No	

CGTLI203285-SP-23/29	AAA40017601	Left/Right Housing	No	
CGTLI203285-SP-24/26	AAA40017401	Left/Right bracket	No	
CGTLI203285-SP-25	AAA61200101	Inductance	No	
CGTLI203285-SP-27	AAA52901401	Spring	No	
CGTLI203285-SP-28	AAA40017701	Button	No	
CGTLI203285-SP-30	AAA40004901	Fixing plug	No	
CGTLI203285-SP-31	AAA40017501	Knob	No	
CGTLI203285-SP-32	AAA52900301	Spring	No	
CGTLI203285-SP-33	AAA53400701	Shaft	No	

CGTLI203285-SP-34	AAA40004701	Lock Sleeve	No	
CGTLI203285-SP-35	AAA51301101	Flower Holder	No	
CGTLI203285-SP-36	AAA60001401	Motor	Yes	
CGTLI203285-SP-37	AAA40005101	Motor End Plate	No	
CGTLI203285-SP-38	AAA52700401	Screw	No	
CGTLI203285-SP-39	AAA52001001	Flat	No	
CGTLI203285-SP-40	AAA20001302	Trimmer Head Assembly	No	
CGTLI203285-SP-41	AAA52712601	The big washer	No	
CGTLI203285-SP-42	AAA52706101	Screw ST4.2x9.5	No	
CGTLI203285-SP-43	AAA51300601	Blade	No	

CGTLI203285-SP-44	AAA52701601	Screw	No	
CGTLI203285-SP-45	AAA40017901	Cover Grass	No	

