





HPWR18008

Spare Part No.	Part No.	Part Name	Easy Damage	Part Picture
HPW R18008-SP-V.A	CC000000075	valve assembly	No	
HPW R18008-SP-C.B	CC000000189	Carbon Brush	No	
HPW R18008-SP-OUTLET.V	TS000000027	YLP03Z check valve assy	No	
HPW R18008-SP-W .S	TS000000904	Y-Ri ng	No	
HPW R18008-SP-O.S	TS00000116	Oil Seal	No	
HPW R18008-SP-INLET.VAL	TS000000026	YLP08Z.1 Inlet Valve Assy	No	
HPW R18008-SP-P.H	TS00000208	Pressure hose	No	
HPW R18008-SP-P.T.B	TS00000313	Plain thrust bearing	No	
HPW R18008-SP-I.S	TS00000315	Inlet Strainer	No	
HPW R18008-SP-S.B	TS00000458	Sealing Base	No	
HPW R18008-SP-C.V.A.S	TS00000460	chief valve assy with self sucNo	No	

HPW R18008-SP-P.A	TS00000470	Piston-Assy	No	
HPW R18008-SP-M.S	TS00000338	Micro Switch	No	
HPW R18008-SP-S.P	TS00000543	Swash plate	No	
HPW R18008-SP-E-3	TS00000899	Gear Box Kit	No	
HPW R18008-SP-E-4	TS00000900	Gear Box	No	
HPW R18008-SP-E-5	TS00000543	Swash plate	No	
HPW R18008-SP-E-8	TS00000313	Plain thrust bearing	No	
HPW R18008-SP-E-12	TS00000805	Valve Plug	No	
HPW R18008-SP-E-13	TS00000027	YLP03Z check valve assy	No	
HPW R18008-SP-E-14	TS00000584	O-Ring 12.5*1.8	No	
HPW R18008-SP-E-16	TS00000904	Y-Ri ng	No	
HPW R18008-SP-E-17	TS00000026	YLP08Z.1 Inlet Valve Assy	No	
HPW R18008-SP-E-20	TS00000903	Oil Seal	No	
HPW R18008-SP-E-21	TS00000803	Sealing Base	No	
HPW R18008-SP-E-22	TS00000804	Piston-Assy	No	
HPW R18008-SP-E-23	TS00000806	chief valve assy	No	
HPW R18008-SP-E-32	TS00000315	Inlet Strainer	No	
HPW R18008-SP-E-33	TS00000338	Micro Switch	No	
HPW R18008-SP-E-2	QX00000255	peach shape ring	No	
HPW R18008-SP-E-6	QX00000256	spring washer ϕ 8		

HPW R18008-SP-E-7	QX00000257	ST screw M8*20/ROHS	No	
HPW R18008-SP-E-9	QX00000258	YLP08 pump kit+gear box kit	No	
HPW R18008-SP-E-10	QX00000259	pump head kit	No	
HPW R18008-SP-E-11	QX00000260	pump head -HC96	No	
HPW R18008-SP-E-15	QX00000261	ST screw M6*8	No	
HPW R18008-SP-E-18	QX00000262	YLP08 piston guider kit	No	
HPW R18008-SP-E-19	QX00000263	P08 piston guider	No	
HPW R18008-SP-E-24	QX00000264	siphon head assembly	No	
HPW R18008-SP-E-25	QX00000265	venturi-tube kit	No	
HPW R18008-SP-E-26	CC000000075	valve assembly	No	
HPW R18008-SP-E-27	QX00000267	o-ring 70X2	No	

HPW R18008-SP-E-28	QX00000268	ST5.5*25	No	
HPW R18008-SP-E-29	QX00000269	small washer ¢ 6	No	
HPW R18008-SP-E-30	QX00000270	spring washer ¢ 6-ROHS	No	
HPW R18008-SP-E-34	QX00000272	motor cover	No	
HPW R18008-SP-Q.A	TS00000408	Quick plug connector body a	No	
HPW R18008-SP-E-26-F	QX00000266	passing valve kit	No	
HPW R18008-SP-ROTOR	TS00001694	rotor	No	
HPWR18008-SP-STATOR	TS00001695	stator	No	
HPWR18008-SP-1	AD001000001	Wheel Cover	No	
HPW R18008-SP-2	AD001000002	Wheel	No	
HPW R18008-SP-3	AD001000003	Screw, ST4.8*16	No	
HPW R18008-SP-4	AD001000004	Warning label	No	
HPW R18008-SP-5	A1002000035	Cable 2*1.0 5m	No	
HPW R18008-SP-6	AD001000005	Accessories Cover	No	
HPW R18008-SP-7	AD001000006	Rear Housing	No	
HPW R18008-SP-8	AD001000007	Detergent Tube Connection	No	

HPW R18008-SP-9	AD001000008	Inner detergent tube L=0.5m	No	
HPW R18008-SP-10	AD001000009	Sealing Block	No	
HPW R18008-SP-11	AD001000010	Screw,ST3x12	No	
HPW R18008-SP-12	AD001000011	Motor clip	No	
HPW R18008-SP-13	AD001000012	Switch Cover	No	
HPW R18008-SP-15	AD001000013	Motor cover cap	No	
HPW R18008-SP-16	AD001000014	Capacitor ass'y 220V/60Hz(ON	No	
HPW R18008-SP-17	AD001W00015	Switch	No	
HPW R18008-SP-18	AD001000016	Swith lever	No	
HPW R18008-SP-19	AD001000017	O-ring, 8.5×1.8	No	

HPW R18008-SP-20	AD001000018	Switch Box	No	
HPW R18008-SP-21	AD001000019	Front housing	No	
HPW R18008-SP-22	AD001000020	Swith deck	No	
HPW R18008-SP-23	AD001000021	Switch button	No	
HPW R18008-SP-24	AD001000022	Handl e	No	
HPW R18008-SP-25	AD001000023	Outer detergent tube L=0.55	No	
HPW R18008-SP-26	AD001000024	Detergent tank	No	

HPW R18008-SP-27	AD001000025	Detergent tank cover	No	
HPW R18008-SP-28	AD001000026	High pressure holder	No	
HPW R18008-SP-29	AD001000027	Screw,ST3.5x20	No	
HPW R18008-SP-32	AD001000028	Spray gun	No	
HPW R18008-SP-33	AD001000029	Adjustable spray lance	No	
HPW R18008-SP-35	AD001000030	High pressure hose	No	
HPW R18008-SP-37	AD001000031	outlet Water deck	No	
HPW R18008-SP-38	AD001000032	Front motor base	No	
HPW R18008-SP-39-A	AD001000034	pump assembly	No	
HPW R18008-SP-39-B	AD001000035	Motor	No	

HPW R18008-SP-39	AD001000033	pump +motor kit 220V/60Hz	No	
HPW R18008-SP-39-C	QX00000164	Whole Pump	No	
HPW R18008-SP-40	AD001000036	Pump base	No	
HPW R18008-SP-41	AD001000037	Screw, M5*18	No	
HPW R18008-SP-42	AD001000038	Screw,ST4.8x20	No	
HPW R18008-SP-43	AD001000039	Right rolling cover	No	
HPW R18008-SP-44	AD001000040	Water connector	No	
HPW R18008-SP-45	AD001000041	Left rolling cover	No	
HPW R18008-SP-46	AD001000042	rating label	No	

