



Spare Part No.	Part No.	Part Name	Easy Damage	Part Picture
ID6808-SP-GUIDE	TS00001151	Guide	No	
ID6808-SP-1	AA004000167	Screw M6*22	No	
ID6808-SP-2	AA004000168	Chuck	No	
ID6808-SP-3	AA004000170	Spindle	No	
ID6808-SP-4	AA004000172	Steel Ball Φ3	No	
ID6808-SP-5	DD00001959	6201 Bearing	No	
ID6808-SP-6	AA004000228	Circlip 12	No	
ID6808-SP-7	AA004000229	Gear	No	
ID6808-SP-8	AA004000230	Circlip 8	No	
ID6808-SP-9	AA004000231	Compressed Spring	No	
ID6808-SP-10	DD00001960	688 Bearing	No	

ID6808-SP-11	AA004000233	Impact Bracket	No	
ID6808-SP-12	AA004000234	Impact iron sheet	No	
ID6808-SP-13	AA004000235	Impact Switch	No	
ID6808-SP-14	DD00001961	608 Bearing	No	
ID6808-SP-15	AA004R00237	Rotor	No	
ID6808-SP-16	AA004S00238	Stator	No	
ID6808-SP-17	AA004000239	Two Teeth Buckle	No	
ID6808-SP-18	AA004000240	Left Housing	No	
ID6808-SP-18/19	DD00003279	Left&Right Housing	No	
ID6808-SP-19	AA004000241	Right Housing	No	

ID6808-SP-20	AA004000242	Brush Holder	No	
ID6808-SP-21	AA004C00243	Carbon Brush	No	
ID6808-SP-22	AA007W00125	Switch	No	
ID6808-SP-23	AA004000245	Screw st4*16	No	
ID6808-SP-24	A1002000073	Cord 2*0.75MM2,1.8M	No	
ID6808-SP-25	AA004000247	Sleeve	No	
ID6808-SP-26	DD00001962	Assist Handle	No	
ID6808-SP-27	DD00003485	Oil flinger ring	No	

