

Spare Part No.	Part No.	Part Name	Easy Damage	Part Picture
JS80068-SP-1	AA008000232	Transparent cover	No	
JS80068-SP-2	AA008000233	The positioning pin 4*49	No	
JS80068-SP-3	AA008000234	Screw M4*14	No	
JS80068-SP-4	AA008000235	Flat Washer ø4	No	
JS80068-SP-5	AA008000236	Flat mat ø4	No	
JS80068-SP-6	AA008000237	Screw M4*20	No	
JS80068-SP-7	AA008000238	Wire block	No	
JS80068-SP-8	AA008000239	Front cover	No	
JS80068-SP-9	AA008000240	Reciprocating rod assembly	No	

JS80068-SP-10	AA008000241	Positioning clamp	No	
JS80068-SP-11	AA008000242	Needle roller bearing HK061	No	
JS80068-SP-12	AA008000243	Flat Washer 6.2*13*0.5	No	
JS80068-SP-13	AA008000244	Round pin 6*17.6	No	
JS80068-SP-14	AA008000245	Gear	Yes	
JS80068-SP-15	AA008000246	Flat Washer 8*17*0.8	No	
JS80068-SP-16	AA008000247	Flat Washer ø8	No	
JS80068-SP-17	AA008000248	Flat Washer	No	
JS80068-SP-18	AA008000249	Flat Washer 15.1*20*0.5	No	

JS80068-SP-19	AA008000250	Spring 0.5*4*12	No	
JS80068-SP-20	AA008000251	Flat Washer ø20	No	
JS80068-SP-21	AA008000252	Screw M5*10	No	
JS80068-SP-22	AA008000253	ball bearing HK090813	No	
JS80068-SP-23	AA008000254	Equilibrator	No	
JS80068-SP-24	AA008000255	Dialing Fork	No	
JS80068-SP-25	AA008000256	Flat Washer 36.5*9*0.5	No	
JS80068-SP-26	AA008000257	Flat Washer 13*6.2*0.5	No	
JS80068-SP-27	AA008000258	Round pin 6*31	No	

JS80068-SP-28	AA008000259	Round pin 5*30	No	
JS80068-SP-29	AA008000260	Flat Washer 10*5.2*0.5	No	
JS80068-SP-30	AA008000261	Felt Seal	No	
JS80068-SP-31	AA008000262	Round pin 9*33.8	No	
JS80068-SP-32	AA008000263	Reduction Gear Box	No	
JS80068-SP-33	AA008000264	Plastic ring	No	
JS80068-SP-34	A1016000000	bearing 6000	No	
JS80068-SP-35	AA008000266	Wind Screen	No	
JS80068-SP-36	AA008000267	Rotor	Yes	

JS80068-SP-37	AA008000268	Brush Holder	No	
JS80068-SP-38	AA008000269	Screw ST3*8	No	
JS80068-SP-39	AA008000270	Carbon Brush	Yes	
JS80068-SP-40	AA008000271	Coil spring	No	
JS80068-SP-41	AA008000272	Screw ST4*65	No	
JS80068-SP-42	AA008000273	Stator	Yes	
JS80068-SP-43	A1010607000	Bearing 607	No	
JS80068-SP-44	AA008000275	Bearing sleeve 607	No	

JS80068-SP-45	AA008000276	Induction magnetic ring	No	
JS80068-SP-46	AA008000277	Housing	No	
JS80068-SP-47	AA008000278	Inductance	No	
JS80068-SP-48	AA008000279	Screw M4*30	No	
JS80068-SP-49	DD00008134	Power cable 2M	No	
JS80068-SP-49-V1	AA008000280	Power Cord 2M	No	
JS80068-SP-50	AA008000126	Cord Potector	No	
JS80068-SP-51	AA008000122	Cable Clip	No	
JS80068-SP-52	AA008000281	Screw ST4*14	No	
JS80068-SP-53/79	AA008000282	Left /Right Housing	No	

JS80068-SP-55	AA008W00128	Switch	Yes	
JS80068-SP-56	AA008000284	Governor	No	
JS80068-SP-57	AA008000285	Shifting gear knob	No	
JS80068-SP-58	AA008000286	Spring 0.45*3.5*9.5	No	
JS80068-SP-59	AA008000287	Flat Washer ø6	No	
JS80068-SP-60	AA008000104	Steel Ball	No	
JS80068-SP-61	AA008000288	Flat Washer ø5	No	
JS80068-SP-62	AA008000289	Purging Switch	No	
JS80068-SP-63	AA008000290	Nut	No	

JS80068-SP-64	AA008000291	Aluminum plate	No	
JS80068-SP-65	AA008000292	Clamp	No	
JS80068-SP-66	AA008000293	Screw M6*16	No	
JS80068-SP-67	AA008000294	Iron plate	No	
JS80068-SP-68	AA008000295	Screw M4*10	No	
JS80068-SP-69	AA008000296	Sole Leather	No	
JS80068-SP-70	AA008000297	Cleaner Pipe	No	
JS80068-SP-71	AA008000298	The toole pin	No	
JS80068-SP-72	AA008000299	Reset spring	No	
JS80068-SP-73	AA008000300	Round pin	No	

JS80068-SP-74	AA008000074	Idler Pulley Axis	No	
JS80068-SP-75	AA008000301	Flat Washer ø4	No	
JS80068-SP-76	AA008000302	Raising Knife Rest	No	
JS80068-SP-77	AA008000303	Idler Pulley	No	
JS80068-SP-78	AA008000304	Screw M4*12	No	
JS80068-SP-80	AA008000306	Screw ST4*18	No	
JS80068-SP-81	AA008000307	Screw	No	
JS80068-SP-82	AA008000308	Linear guide	No	
JS80068-SP-83	AA008000309	Hexagon wrench M4	No	
JS80068-SP-84	AA008000310	Hexagon wrench M6	No	

