


Spare Part No.	Part No.	Part Name	Easy Damage	Part Picture
WLC15008-SP-1	AA048000001	Knob M5	No	
WLC15008-SP-2	AA048000002	Knob M6	No	
WLC15008-SP-3	AA048000003	Guage Holder	No	
WLC15008-SP-4	AA048000004	Cutting Depth Guage	No	
WLC15008-SP-5	AA048000005	Side Handle	No	
WLC15008-SP-6	AA048000006	Disc Cover Plate	No	
WLC15008-SP-7	AA048000007	Screw M6*25	No	
WLC15008-SP-8	AA048000008	Fixed Guard Cover	No	
WLC15008-SP-9	AA048000009	Outer Flange	No	

WLC15008-SP-10	AA048000010	Cutting Width Setting Plate	No	
WLC15008-SP-12	AA048000012	Inner Flange	No	
WLC15008-SP-13	AA048000013	Moveable Guard	No	
WLC15008-SP-14	AA048000014	Screw M6*25	No	
WLC15008-SP-15	AA048000015	Washer $\Phi 16 \times \phi 6.5 \times 1.5$	No	
WLC15008-SP-16	AA048000016	Screw M6	No	
WLC15008-SP-17	AA048000017	Fixed Guard Seat	No	
WLC15008-SP-18	AA048000018	Bolt	No	
WLC15008-SP-19	AA048000019	Washer M8	No	

WLC15008-SP-20	AA048000020	Steel Bushing	No	
WLC15008-SP-21	AA048000021	Wheels	No	
WLC15008-SP-22	AA048000022	Screw M8*30	No	
WLC15008-SP-23	AA048000023	Out Dust Tube Seat	No	
WLC15008-SP-24	AA048000024	Screw M4X10	No	
WLC15008-SP-25	AA048000025	Out Dust Tube Anti-Dust Ring	No	
WLC15008-SP-26	AA048000026	Out Dust Tube	No	
WLC15008-SP-27	AA048000027	Spindle	No	
WLC15008-SP-28	AA048000028	Dust Cover	No	
WLC15008-SP-29	AA048000029	Screw M5X16	No	

WLC15008-SP-30	AA048000030	Gear Box Cover	No	
WLC15008-SP-31	AA048000031	O-Ring $\Phi 2 \times \Phi 49.5$	No	
WLC15008-SP-32	A1016203000	6203 Bearing	No	
WLC15008-SP-33	AA048000032	Retainer Ring $\phi 40$	No	
WLC15008-SP-34	AA048000033	Key 5*5*16	No	
WLC15008-SP-35	AA048G00034	Gear	Yes	
WLC15008-SP-36	AA048000035	O-Ring $\Phi 1 \times \Phi 5.8$	No	
WLC15008-SP-37	AA048000036	External Criclips $\Phi 15$	No	
WLC15008-SP-38	AA048000037	Spindle Lock	No	
WLC15008-SP-39	A1010626000	Bearing 626	No	

WLC15008-SP-40	AA048000038	Gear Housing	No	
WLC15008-SP-41	AA048000039	Screw St5X35	No	1
WLC15008-SP-42	AA048000040	Spring	No	
WLC15008-SP-43	AA048000041	Spingdle Lock Cap	No	
WLC15008-SP-44	AA048000042	Nut M8	No	
WLC15008-SP-45	DD00008946G	Pinion	Yes	
WLC15008-SP-46	DD00000437	Bearing 6200	No	
WLC15008-SP-46-F A1016002000		Bearing 6002-RS	No	
WLC15008-SP-47	AA048000044	Washer $\Phi 30 \times \Phi 20 \times 1$	No	
WLC15008-SP-48	AA048000045	Retainer Ring $\Phi 30$	No	

WLC15008-SP-49	AA048R00046	Rotor	Yes	
WLC15008-SP-50	AA048000047	Anti-Dust Ring	No	
WLC15008-SP-51	A1010608000	Bearing 608	No	
WLC15008-SP-52	AA002000051	Bearing Sheath	No	
WLC15008-SP-53	AA048000048	Baffle	No	
WLC15008-SP-54	AA048000049	Screw St5X65	No	
WLC15008-SP-55	AA048S00050	Stator	Yes	
WLC15008-SP-56	AA048000051	Housing	No	
WLC15008-SP-57	AA048000052	Carbon Brush Holder	No	
WLC15008-SP-58	AA048C00053	Carbon Brush	Yes	
WLC15008-SP-59	AA048000054	Coil Spring	No	

WLC15008-SP-60	AA048000055	Screw St4*12	No	
WLC15008-SP-61	AA048000056	carbon brush cover	No	
WLC15008-SP-62	AA048000057	Left Handle	No	
WLC15008-SP-62/66	DD00010084	Left and right handle	No	
WLC15008-SP-63	AA048000058	Cable Clamp	No	
WLC15008-SP-64	AA048000059	Screw St4X14	No	
WLC15008-SP-65	AA048W00060	Switch	Yes	
WLC15008-SP-66	AA048000061	Right Handle	No	
WLC15008-SP-67	AA048000062	Cord Guard	No	
WLC15008-SP-68	AA048000063	Power Plug & Cord 2M	No	

WLC15008-SP-69	AA048000064	Screw M5X45	No	
WLC15008-SP-70	AA048000065	Screw St4X19	No	
WLC15008-SP-BS	AAAC0000835	Power cord 2 * 1mm ² 2m rubNo		
WLC15008-SP-C.B	BC00000303	Color box	No	
WLC15008-SP-P.M	BC00000529	Product manual	No	
WLC15008-SP-R.R	TS00003646	Reducing ring	No	
WLC15008-SP-WRENTS00000382		wrench	No	

